

Front Disc Mounting all bikes without ABS (ARA-Dxx)

Secure the bike on a stand and remove the wheels.



Remove the brake disc bolts.



Clean the bolts (remove the threadlocker) and clean that part of the brake disc which will be in contact with the ARA disc.



Front Disc Mounting all bikes without ABS (ARA-Dxx)

Mount the supplied ARA disc.

Apply new threadlocker on the bolts.

Tighten the bolts to the value specified in the Service Manual. Use a torque wrench.



Put the wheel back.

Tighten the bolts to the value specified in the Service Manual. Use a torque wrench.

Next, install the ARA wheel sensor (ARA-WSS). This step is bike model specific thus it's not covered in this document.

