



SUPPLEMENTARY MANUAL

for GPDT-H01

REMOVE THE SEAT.



REMOVE THE SIDE COVERS AND THE
SIDE FAIRINGS.

REMOVE OR LIFT UP THE FUEL
TANK.



LOCATE THE THE
DIAGNOSTIC SYSTEM CONNECTOR
UNDER THE SEAT.
(RED, 4-POLE CONNECTOR WITH RED CAP.)






SUPPLEMENTARY MANUAL

for GPDT-H01

CONNECT THE GIPRO CONNECTOR
TO THE
DIAGNOSTIC SYSTEM CONNECTOR.



TYPICAL POSITION FOR THE
GEAR INDICATOR.

