


SUPPLEMENTARY MANUAL

for GPX-HO1


REMOVE THE SEAT.

LIFT UP OR REMOVE THE

FUEL TANK.




REMOVE THE AIRBOX COVER.



PLUG GPX CONNECTORS IN-LINE
WITH THE SPEED SENSOR
CONNECTORS.

 $(\mathsf{BLACK},\ \mathsf{3\text{-}POLE}\ \mathsf{CONNECTORS}$ In dust boot on left side below airbox cover)






CONNECT GPX BLACK/GREEN WIRE TO

YELLOW WIRE OF CRANKSHAFT POSITION SENSOR CONNECTOR.

(BLUE, 2-POLE CONNECTOR

IN DUST BOOT ON LEFT SIDE BELOW AIRBOX COVER)



TYPICAL POSITION FOR THE GEAR INDICATOR.

