

**Yamaha YZF-R1**  
2002-2003



**SUPPLEMENTARY MANUAL**

for GPXT + GPX-Y01

REMOVE THE MAIN SEAT.



LIFT UP OR REMOVE THE  
FUEL TANK.



PLUG THE GPX CONNECTORS IN-  
LINE WITH THE SPEED SENSOR  
CONNECTORS.

(WHITE, 3-POLE TRIANGULAR CONNECTORS  
AT THE RIGHT SIDE.)





# SUPPLEMENTARY MANUAL

for GPXT + GPX-Y01

CONNECT THE GPX BLACK/GREEN  
WIRE TO THE GRAY WIRE OF  
THE CRANKSHAFT POSITION SENSOR  
CONNECTOR.

(TRANSPARENT, 2-POLE CONNECTOR  
AT THE RIGHT SIDE.)



CONNECT THE GPX RED WIRE TO  
THE BROWN WIRE OF THE REAR  
BRAKELIGHT SWITCH CONNECTOR.

(BROWN, 2-POLE CONNECTOR  
AT THE RIGHT SIDE.)



TYPICAL POSITION FOR THE  
GEAR INDICATOR.

